




7 - 14 pH ; 1 - 300 mg/L Cl_2 ; 10 - 200 mg/
L Cl_2




Attention! Select the appropriate sample volume according to the instructions in the chapter Sampling.



Add **6 drops Free Chlorine Buffer FCL1**. **Note:** Add 10 drops when hardness of sample is greater than 400 mg/l (as CaCO_3).



Attention! Record the number of drops that will be added. **Note:** Make sure to swirl the jar after adding each drop!



Add **Chlorine Free LR Titrant FCL2** or **Chlorine Free HR Titrant FCL3** drop by drop to the sample until colouration turns from colourless/pale yellow to blue.

Calculate test result: Free Chlorine (as Cl_2) mg/L = Number of drops x factor (see table)