

Surfactants M. (anion.) TT

M376

0.05 - 2 mg/L SDSA

Methylene Blue

## Instrument specific information

The test can be performed on the following devices. In addition, the required cuvette and the absorption range of the photometer are indicated.

Instrument Type	Cuvette	λ	Measuring Range
MD 600, MD 610, MD 640, MultiDirect, SpectroDirect, XD 7000, XD 7500	ø 16 mm	660 nm	0.05 - 2 mg/L SDSA

#### **Material**

Required material (partly optional):

Reagents	Packaging Unit	Part Number
Surfactants (anionic) Spectroquant 1.02552.0001 tube test d)	25 pc.	420763

## **Application List**

· Waste Water Treatment

# **Preparation**

- Because the reaction depends on temperature, the temperature must be maintained at 10-20 °C (for the reaction vial and the water sample).
- 2. Invert the vial prior to the measurement. Should the lower phase be turbid, warm the cell briefly with the hand.



#### **Notes**

- 1. This method is adapted from MERCK.
- 2. Spectroquant® is a registered trademark of the company MERCK KGaA.
- 3. Appropriate safety precautions and good laboratory technique should be used during the whole procedure.
- Before performing the test, you must read through the original instructions and safety advice that is delivered with the test kit (MSDS are available on the homepage of www.merckmillipore.com).
- Sample volume should always be metered by using a 5ml volumetric pipette (class A)
- The reagents are to be stored in closed containers at a temperature of +15 °C +25 °C.
- MBAS = Methyleneblueactive Substances, calculated as sodium 1-dodecanesulfonate




## Determination of Anionic surfactants with MERCK Spectroquant® Cell Test, No. 1.14697.0001

Select the method on the device.

For this method, a ZERO measurement does not have to be carried out every time on the following devices: XD 7000, XD 7500

Skip steps with Blank.




5 mL



Mark one as a blank.

Prepare two reaction vials. Put 5 mL deionised water Do not mix the contents in the blank.



Put 5 mL sample in the sample vial.




Do not mix the contents




Hold cuvettes vertically and add equal drops by pressing slowly.



Add 2 drops Reagenz T-1 K solution to each vial.




Close vial(s).




Mix the contents by shaking. (30 sec.).






Press the  ${\bf ENTER}$  button.



Wait for 10 minute(s) reaction time.




Invert zero cuvette.



Place **blank** in the sample chamber. • Pay attention to the positioning.




Press the **ZERO** button.



Remove **vial** from the sample chamber.



Invert the sample vial .



Place **sample vial** in the sample chamber. • Pay attention to the positioning.



Press the **TEST** (XD: **START**)button.

The result in mg/L MBAS appears on the display.



## **Analyses**

The following table identifies the output values can be converted into other citation forms.

Unit	Cite form	Scale Factor
mg/l	SDBS	1.28
mg/l	SDS	1.06
mg/l	SDOSSA	1.63

#### **Chemical Method**

Methylene Blue

## **Appendix**

## Calibration function for 3rd-party photometers

Conc. = a + b•Abs + c•Abs<sup>2</sup> + d•Abs<sup>3</sup> + e•Abs<sup>4</sup> + f•Abs<sup>5</sup>

Ø	1	6	m	m

а	1.36547 • 10 <sup>-2</sup>
b	1.8329 • 10+0
С	
d	
е	
f	

#### According to

DIN EN 903:1994

d) Spectroquant® is a Merck KGaA Trademark